

### Panasonic Lumix Quick-Start Guide

\*\*Full user manual available on our website: <http://www.uwb.edu/it/howdoi/circulating-equipment>\*\*

1. How to shoot stills in auto mode
  - i. Turn the camera on
  - ii. Turn the knob on top of the camera to "iA", or Intelligent Auto Mode.
  - iii. Point the camera at an object. The camera will display an icon in the upper left hand side of the screen depicting the type of scene recognized.
  - iv. Take a picture

2. How to shoot video
  - i. Press the motion picture button on the top of the camera:



- ii. Press the button a second time to end the recording.
3. How to use the touch screen
  - i. To open the menu, press "A" – the middle button on the back of the camera
  - ii. To navigate the menu, either touch the screen or use the buttons surrounding "A" – up down, right, and left.