

R20 & G20: Moving Media from Built-In Memory to SD card


1) The videos/photos must be stored in the internal memory in order to be moved to card A or card B

2) To access the scenes you wish to copy, press the (camera/play) button.

3) After pressing the (Camera/Play) button, press the "Edit" tab at the bottom of the screen.

4) Press the "Copy → A" or "Copy → B" tab

5) Choose from desired option



R20: How to Record onto SD Card

1. Press "Func." on the screen
2. Press "Menu" on the screen
3. Select the middle tab in the menu
4. Select "Rec Media for Movies"
5. Choose the SD card slot your card is in

